WATER PRO
Great Water, Great Life.

How to Bypass a Whole House System

In the event of a leak, bypass whole system

BYPASS VALVE OPERATION

NORMAL OPERATION



BYPASS OPERATION



During **Normal** Operation, the arrows on the bypass valves should be pointing in the same direction as the flow of water in and out of the system.

During **Bypass** Operation, the arrows on the bypass valves should be facing each other creating a straight line and blocking any water flow from going in or out of the system.

To put a system in bypass, turn both valves (*arrows/knobs may be red or black*) ¼ turn in the direction of the arrow or OFF/Bypass lettering on the valves.

Call Water Pro for service if a leak occurs (804) 693-7294

Water Pro 9977 John Clayton Mem Hwy, Gloucester, VA 23061
www.WaterProInc.com | (804) 693-7294 | info@waterproinc.com